CROP DIVIDER

INSTALLATION MANUAL

CASE SPRAYER MOUNT POST 2016

FREEFORM PLASTICS

BOX 159, ST. BRIEUX, SK CANADA SOK 3V0

P: 1-306-275-2155 F: 1-306-275-2101

EMAIL: SALES@FREEFORMPLASTICS.COM WEB SITE: WWW.FREEFORMPLASTICS.COM

Page | 1 26008-31

NOTES

- LOCTITE ALL FASTENERS THAT ARE NOT SELF LOCKING
- ONLY RIGHT SIDE SHOWN

TOOLS REQUIRED

- RED LOCTITE
- 20mm 12 POINT WRENCH OR SOCKET
- 30mm WRENCH OR SOCKET
- 24mm WRENCH OR SOCKET

INSTALLATION INSTRUCTIONS

- 1. REMOVE SPRAYER BOLTS
- REMOVE NUTS ON AXLE PIVOT ENSURING TO KEEP WASHERS
- LEAVE BOLTS HANGING THROUGH



Page | 2 26008-31

2. MOUNT BRACKETS

- ENSURE WASHERS FROM PREVIOUS STEP ARE BETWEEN DIVDER MOUNT AND THE AXLE PIVOT.
- FASTEN DIVIDER MOUNT TO AXLE PIVOT AND TOURQUE TO MACHINE SPECIFICATIONS.
- BOLT TO AXLE PIVOT USING THE FOLLOWING FASTENERS:


1088-19 BOLT M16 X 35 GR8.8 QTY 1
1326-31 WSH FLAT M16 YZ QTY 1



*ABOVE FIGURE MAY REFLECT PREVIOUS REVISIONS

3. REPEAT FOR LEFT SIDE ASSEMBLY

Page | **3** 26008-31



Page | 4 26008-31