

---

# **CROP DIVIDER**

---

# **INSTALLATION MANUAL**

---

## **AGRIFAC CONDOR ENDURANCE II**

---

### **FREEFORM PLASTICS**

BOX 159, ST. BRIEUX, SK CANADA

S0K 3V0

P: 1-306-275-2155

F: 1-306-275-2101

EMAIL: SALES@FREEFORMPLASTICS.COM

WEB SITE: WWW.FREEFORMPLASTICS.COM

## NOTES

- LOCTITE ALL FASTENERS THAT ARE NOT SELF LOCKING
- ONLY LEFT SIDE SHOWN

## TOOLS REQUIRED

- RED LOCTITE
- 13MM SOCKET
- 9/16" DRILL BIT (MULTIPLES MAY BE REQUIRED AND SIZES LEADING UP TO 9/16")
- CUSTOM T-BOLT W/ NUT (UNDER PASSENGER SEAT OF SPRAYER)
- 24MM WRENCH
- 3/4" WRENCH AND SOCKET

## INSTALLATION INSTRUCTIONS

1. REMOVE MUD GUARDS
  - UNFASTEN MUD GUARD. THERE ARE TWO BOLTS ON THE FRONT AND TWO BOLTS UNDERNEATH A FLANGE IN THE REAR.



## 2. DRILL HOLES LARGER

- ONCE THE MUD GUARD IS OFF THE FOUR HOLES WILL HAVE TO BE DRILLED LARGER TO 9/16".



## 3. RELEASE BRAKES

- REMOVE SEAL OFF THE TOP OF THE BRAKES.
- PLACE CUSTOM T-BOLT INSIDE AND TIGHTEN THE NUT.
- SLIGHTLY LOOSEN BOTTOM NUTS UNDER THE BRAKES.
- CONTINUE TO TIGHTEN THE NUT ON THE T-BOLT UNTIL THE BOTTOM NUTS ARE LOOSE.
  - LOOSEN BOTTOM NUTS UNTIL THEY ARE HELD ON BY ONE OR TWO THREADS.



4. FASTEN DIVIDER MOUNT WELDMENT TO AXLE

- SLIDE BRACKET BETWEEN THE BRAKE NUTS AND PLATES WHILE ROTATION UPWARDS. USE THE FOLLOWING FASTENERS TO SECURE THE MOUNTS TO THE SPRAYER:

○ 1007-12	BOLT 1\2X2 UNC GR8 PLD	QTY 4
○ 1204-05	NUT PTRQ PLD 1\2 UNC GR B ZDW	QTY 4
○ 1325-30	WSHR 1\2 PL PLD	QTY 8



5. TIGHTEN ALL BOLTS, RELEASE THE BRAKES & REPEAT ON THE RIGHT SIDE.

